<u>PIMP MY WINDOWS</u> INSTALLATION STEPS AFTER QUOTE ACCEPTANCE

Collection & delivery of new aluminium joinery to the site.





Existing rotten timber windows to be replaced.







Apply Sill wrap tape & Sill flashing or paint seal blockwork.









New windows installed.









Cut & Fit internal architraves.





Cut & Fit timber Scribers or aluminium finishing angles to the outside of the new aluminium joinery.







Load up and the removal of all old joinery and rubbish



